

■ NEED TO ADD FEMALE PIN CONNECTORS

MALE PINS

ADD GROUND & BOTH JUMPER WIRES AS SHOWN ABOVE BY DOTTED LINES TO MATCH U.S. PLUG-IN ON TURN SIGNALS. TAPE OFF OR REMOVE PLUG & WIRES TO HIGH BEAM ONLY SIDE OF THE FOUR-LIGHT HARNESS.