## Hardtop Cart Assembly Instructions



## **Parts List**

- 1. (3) Bolts
- 2. (1) Nut
- 3. (1) Washer
- 4. (2) 36 inch round bars
- 5. (2) 29 inch round bars with large hole
- 6. (1) 29 inch round bar with small hole
- 7. (2) Locking wheels with bolt
- 8. (2) Non-locking wheels with bolt
- 9. (2) Large "L" brackets

## **Tool Required**

1. Open-end wrench

## **Instructions**

- 1. Take the 29 inch round bar with the smaller end holes and loosely fasten it with 2 bolts across the top parts of the "L" brackets.
- 2. Take the two 36 inch bars and make them into an "X" shape and loosely fasten the remaining nut, washer, and bolt through the center hole.
- 3. Lay the "L" brackets on the ground with the short legs facing up. Take the "X" round bars and align them with the holes in the bottom of the "L' brackets. Take one of the remaining 29 inch round bars and put the locking wheel with the bolt through both round tube ends. Put the nut on the top of the wheel bolt. Repeat with the other locking wheels.
- 4. Take the non-locking whels and put the bolt through one of the other two remaining ends and then repeat with the last wheel.
- 5. Tighten all nuts and bolts to make card rigid and sturdy.

