

Bluetooth Activation Instructions



Instructions

Once the radio is installed, you need to “pair” it with your phone or device.

To pair, turn the radio ON, open the SETTINGS menu on your phone/device, select BLUETOOTH.

Slide the switch on the Settings Screen to ON to turn Bluetooth on and review the My Devices window. you will notice other Bluetooth devices you have previously paired. Once this modified radio has ben paired, JC-AUDIO-BT625 will appear under My Devices.

Access the modified radio through the following modes:

BECKER

Model 612 / 754 - ANY mode

Model 780 / 1480 - ANY mode

Model 1432 - Cassette Mode (cassette must be inserted)

Model 1492 / 1692 - FM Mode

Model 3302 / 3309 / 6003 - Cassette Mode (cassette must be inserted)

All Classic Europa / Mexico - Any Mode

ALPINE

Model CM2294 / CM2396 - FM Mode

Model CM1910 - Cassette Mode (cassette must be inserted)

adsit
& HIS German Auto Parts